Operating instructions

for vented tumble dryer
T 7634

To avoid the risk of accidents or damage to the appliance it is **essential** to read these instructions before it is installed and used for the first time.

en - GB

M.-Nr. 07 856 790

Caring for the environment

Disposal of the packing material

The transport and protective packing has been selected from materials which are environmentally friendly for disposal and should be recycled.

Ensure that any plastic wrappings, bags, etc are disposed of safely and kept out of the reach of babies and young children. Danger of suffocation.

Disposal of your old appliance

Electrical and electronic appliances often contain materials which, if handled or disposed of incorrectly could be potentially hazardous to human health and to the environment. They are, however, essential for the correct functioning of your appliance. Please do not therefore dispose it with your household waste.

Please dispose of it at your local community waste recycling centre or contact your dealer for advice. Ensure that it presents no danger to children while being stored for disposal.

Energy saving tips

To avoid unnecessarily long drying times and high consumption of energy:

– Make sure that your laundry is thoroughly spun before drying.

  The higher the spin, the greater the savings that can be made in energy and time during drying.

– Load according to the optimum amount of laundry recommended for the programme being used (see "Programme chart").

  Underloading is uneconomical. Overloading gives a poorer quality of drying and may cause unnecessary creasing.

– Make sure the room in which the dryer is located is well ventilated.

– Make sure the fluff filter is clean before using the dryer.

– Check all parts of the ventilation system on a regular basis and remove any build up of fluff etc.

– The vent ducting should be as short, straight and smooth as possible to minimise any resistance to the air throughflow.

Contents

Caring for the environment 2
Warning and Safety instructions 5
Operating the tumble dryer 13
Control panel 13
Notes on laundry care 15
Care symbols 15
Tips on drying 15
How to dry correctly 16
Brief instructions 16
Extra options / Delay start 19
Low temperature 19
Buzzer 19
Delay start 19
Programme chart 20
Changing the programme sequence 23
Once a programme has started 23
- changing the programme 23
- cancelling the programme and then selecting a different programme 23
- cancelling the programme and then removing the laundry 23
Altering Delay start 23
Adding or removing laundry after a programme has started 23
Time remaining 23
Electronic system lock 24
Cleaning and care 25
Cleaning the fluff filter 25
Cleaning the grilles in the door opening 26
Cleaning the tumble dryer 26
Problem solving guide 27
Check and fault messages 27
Other problems 29
Changing the lamp 32
After sales service 33
Repairs 33
Future updates (PC) 33
Guarantee 33
Optional accessories 33

Contents

Installation and connection 34
Front view 34
Rear view 35
Installation site 35
Transporting the machine to its installation site 35
Washer-dryer stack 35
Levelling the machine 36
Room ventilation 36
Electrical connection 37
Electrical connection U.K. 37
Installation - venting 38
General 38
Calculating the total duct length : 39
Installation to the rear, left or right side of the appliance 40
Venting systems 41
Ⓐ Flexible ducting hose 41
Ⓑ Plastic piping 43
Ⓒ Connect directly to a wall vent 44
Washer-dryer stack 45
Consumption data 46
Technical data 47
Programmable functions 49
Altering the residual moisture level in the Cottons programme 49
Altering the residual moisture level in the Minimum iron programme 50
Anti-crease 51
Altering the volume of the buzzer 52
Altering the standard drying level in the Automatic programme 53
Extending the cooling down time 54
Standby 55
Memory function 57
Clean out airways indicator 58
Keypad tone 59
Adjusting the dryer's electronics for very soft water 60
Extending the range of the drying levels 61



▶ It is **essential** to read these instructions.

This tumble dryer conforms to current safety requirements. Inappropriate use can, however, lead to personal injury and damage to property.

To avoid the risk of accidents and damage to the tumble dryer, please read these instructions carefully before using it for the first time. They contain important information on its safety, installation, use and maintenance.

Keep these instructions in a safe place and ensure that new users are familiar with the content. Pass them on to any future owner.

Correct application

▶ This tumble dryer is not designed for commercial use. It is intended for use in domestic households and similar working and residential environments.

▶ The tumble dryer is not intended for outdoor use.

▶ It must only be used as a domestic appliance to dry items which have been washed in a water solution and which are marked on the manufacturer's care label as being suitable for tumble drying. If using dry cleaning kits, do so at your own risk, and follow the instructions provided on the packaging.
Any other usage is not supported by the manufacturer and could be dangerous. Miele cannot be held liable for damage resulting from incorrect or improper use or operation.

▶ The tumble dryer can only be used by people with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, if they are are supervised whilst using it or have been shown how to use it in a safe way and understand the hazards involved.

Safety with children

▶ Children under 8 years of age must be kept away from the tumble dryer unless they are constantly supervised.

▶ Children 8 years and older may only use, clean or maintain the tumble dryer without supervision if they have been shown how to do so in a safe way and understand the hazards involved.

▶ The tumble dryer is not a toy! To prevent the risk of injury, do not allow children to play with it or near it, or to play with the controls.

Technical safety

▶ Before setting up the tumble dryer, check it for any externally visible damage.
Do not install or use a damaged tumble dryer.

▶ Before connecting the tumble dryer, ensure that the connection data on the data plate (voltage and frequency) match the mains electricity supply. If in any doubt, consult a qualified electrician.

▶ The electrical safety of this tumble dryer can only be guaranteed when correctly earthed. It is most important that this basic safety requirement is observed and regularly tested, and where there is any doubt, the household wiring system should be inspected by a qualified electrician. Miele cannot be held liable for the consequences of an inadequate earthing system (e.g. electric shock).

▶ Do not connect the tumble dryer to the mains electricity supply by an extension lead. Extension leads do not guarantee the required safety of the tumble dryer (e.g. danger of overheating).

▶ If the electrical connection cable is faulty it must only be replaced by a Miele approved service technician to protect the user from danger.

▶ Unauthorised repairs could result in unforeseen dangers for the user, for which Miele cannot accept liability. Repairs should only be undertaken by a Miele approved service technician, otherwise any subsequent damage will not be covered by the guarantee. Ensure current is not supplied to the tumble dryer until after maintenance or repair work has been carried out.

▶ Faulty components must only be replaced by genuine Miele original spare parts. Only when these parts are fitted can the safety standards of the tumble dryer be guaranteed.

▶ The tumble dryer must be isolated from the electricity supply in the event of a fault and during cleaning and maintenance.

▶ The tumble dryer must not be used in a non-stationary location (e.g. on a ship).

▶ Do not make any alterations to the tumble dryer, unless authorised to do so by Miele.

▶ In areas which may be subject to infestation by cockroaches or other vermin, pay particular attention to keeping the tumble dryer and its surroundings in a clean condition at all times. Any damage which may be caused by cockroaches or other vermin will not be covered by the guarantee.

Correct use

▶ To prevent the risk of fire, the following textiles must not be dried in this appliance:

– items which have not been washed.

– items, such as workwear, which have not been thoroughly cleaned and which are still soiled with grease, oil or other deposits (such as cosmetics, lotions etc).
If items have not been thoroughly cleaned there is a danger that these might self-ignite when heated, even after they have been removed from the dryer at the end of the programme.

– items (e.g. mops and floor cloths) which have been treated with inflammable cleaning agents or which contain residues of acetone, alcohol, benzine, petrol, kerosene, stain remover, turpentine, wax and wax remover or other chemicals.

– items which have been splashed with hair lacquer, hair spray, nail varnish remover or similar substances.

When washing such heavily soiled items, ensure that you use additional detergent and select a high temperature. If in doubt, wash the items several times.

▶ Remove all items such as lighters and matches from pockets.

▶ **Warning**: Do not switch the tumble dryer off before the drying programme has finished. If this is done, the laundry must be hung up or spread out to cool it down.

▶ Danger.
This tumble dryer must not be connected to a controllable socket (e.g. a timer switch or a peak load shut-off device).
If the dryer programme were to be interrupted before the end of the cooling down phase, the laundry could self-combust.

▶ To prevent the risk of fire, the following must not be tumble dried:
– items which have been cleaned using chemicals (e.g. professional dry-cleaning agents).
– fabrics which contain a large proportion of rubber, foam rubber or rubber-like materials. For example, products made from latex foam rubber, shower caps, waterproof textiles, rubberised articles and items of clothing and pillows with foam rubber filling.
– damaged items which contain padding or fillings (e.g. pillows, jackets). When damaged, the filling can get out with the risk of igniting in the dryer.

▶ In many programmes, the heating phase is followed by a cooling down phase to ensure that the items are not too hot to handle when you remove them (this also avoids the danger of the laundry self-igniting). The programme is not finished until the cooling down phase has been completed.
As soon as the programme has finished, remove all laundry from the drum.

▶ Fabric conditioner and similar products must be used according to the instructions on the manufacturer's packaging.

▶ Do not let anyone sit or lean on the door, as this can cause the tumble dryer to tip up.

▶ Always close the door after use. This way you will avoid the danger of:
– children climbing into the dryer or hiding things in it.
– pets or other small animals climbing into it.

▶ The tumble dryer must not be used without the fluff filter in place or if the fluff filter is damaged in any way.

▶ The fluff filter must be cleaned regularly.

▶ The dryer must not be used without vent ducting in place.

▶ The dryer must not be connected to a chimney or vent flue which is in use.

▶ Do not install the tumble dryer in a room where there is a risk of frost occurring. At temperatures around freezing point the tumble dryer may not be able to operate properly. The ambient room temperature should be between +2°C and +35°C.

▶ Check all parts of the extraction system on a regular basis (e.g. wall vent, external grille, bends in the ducting etc.) and make sure they are all free of any hindrance. A build-up of fluff will prevent a free flow of air through the system. If the dryer is to be connected to an existing ducting system, this must be checked for suitability beforehand.

▶ The exhaust air must not be vented into a chimney or vent flue which is in use, nor should it be connected to ducting which ventilates rooms with fireplaces. It would be dangerous if smoke or exhaust fumes were drawn back into the room.

▶ Adequate ventilation is essential **to avoid the danger of asphyxia and toxic fumes** where another appliance which also uses the room air (e.g. gas, oil or coal fired heater, continuous flow or other water heater) is installed in the same or an adjacent room. To ensure safe operation, and to prevent gases given off by these appliances being drawn back into the room, an underpressure of 4 Pa is the maximum permissible.
Ventilation can be maintained by:

– air inlets in the external wall which cannot be closed or blocked, or
– by fitting a window contact switch which ensures that the tumble dryer can only be operated when the window is open.

To ensure safe operation of your dryer and to avoid an underpressure of 4 Pa or more, please seek professional advice.

▶ Always keep the area around the tumble dryer free of dust and fluff. Dust drawn into the tumble dryer can cause blockages.

▶ The tumble dryer must not be hosed down.

Accessories

▶ Only use genuine Miele original spare parts and accessories with this tumble dryer.
If non-Miele parts are used, guarantee, performance and product liability claims may be invalidated.

Miele cannot be held liable for damage caused by non-compliance with these Warning and Safety instructions.

Control panel



① Display

See next page for details

② *Delay start* button

This button is used for:
- Selecting the duration of the *Warm air* and *Cool air* programmes
- Delaying the start of a programme

③ *Buzzer* button

An audible tone sounds at the end of the programme.

④ Check lights

These indicator lights have various functions. See "Cleaning and Care" and "Problem solving guide" / "After sales service" for further details.

⑤ *Start/Stop* button

For starting the programme selected and cancelling a programme once it has started.
The button flashes while a programme is being selected and then is on constantly when the programme has started.

⑥ *Low temperature* button

Delicate fabrics are dried at a lower temperature.

⑦ Drying level button

with indicator lights to show the level selected

⑧ Programme selector

lights to show the programme selected

⑨ *Door* button

Pressing this button will open the door even when the machine is switched off at the mains.

⑩ *On/Off* button I O

For switching the dryer on and off.

Display

The following are selected via the display:

– Delay start

– Duration of the Cool air and Warm air programmes

– Programmable functions

The display also shows:

– Programme duration

– Programme stage
Drying
Cooling down
Finish

– Check and fault messages

Programme duration / Estimated time remaining

When a programme is selected, the estimated duration (time remaining) will appear in the display. Please be aware that it is only an estimate!

The following factors all affect the estimated time remaining: residual moisture content after spinning; type of fabric; size of load; room temperature; fluctuations in power supply.

The electronics continually assess conditions in the dryer and adjust the estimated time remaining for a more accurate reading. Because of this, the time displayed can alter during the course of a programme.

In the same way, the *Woollens handcare, Silks handcare* and *Smoothing* programmes can finish earlier than expected if a certain temperature is reached. This can happen with particularly fine fabrics, very small loads or if items were partly dry beforehand.

Delay start

The delay start time selected will appear in the display.

After the Start/Stop button has been pressed, the delay start time will start counting down.

Once the delay start time has elapsed, the programme will begin and the estimated programme duration will appear in the display.

Programmable functions

The programmable functions can be used to tailor drying programmes to suit your individual requirements. In programming mode, the display will show the function selected.

Care symbols

Before drying check the drying symbol on the care label. If there are no symbols, dry at your own risk!

⊡ . . . . . Dry at normal temperature
⊡. . . . . Dry at low temperature
⊠ . . . . . Do not tumble dry

Tips on drying

– Always observe the maximum recommended loads given in the "Programme chart". Never overload the drum.

Overloading can cause unnecessary wear and tear to the laundry, give a disappointing drying result and cause more creasing.

– Do not put soaking wet items into the tumble dryer. Spin them thoroughly after washing using the appropriate spin speed.

– For delicates and fabrics with the following care label ⊡ select *Low temperature*.

– Use the *Automatic* programme for drying mixed loads of cottons and minimum iron fabrics.

– Open jackets so that they can dry evenly.

– Woollens and wool blends tend to become matted and shrink if dried in a tumble dryer. They can, however, be partially dried using the *Woollens handcare* programme.

– Down-filled garments have linings which have a tendency to shrink, depending on the quality of the item. They can be partially dried using the *Smoothing* programme.

– Pure linen should only be machine dried if specified as suitable by the manufacturer on the care label, as the surface of the fabric may otherwise become rough. They can be partially dried using the *Smoothing* programme.

– Loopknit garments (e.g. T-shirts and underwear) tend to shrink depending on their quality. Do not over-dry these textiles. When purchasing these garments it is advisable to take their shrinkage properties into account.

– For garments made from very fine weave fibres, such as shirts or blouses, only use the *Shirts* or *Delicates* programme to avoid creasing. If in doubt, reduce the load or use the *Smoothing* programme.

– Starched laundry can be dried in the tumble dryer. To achieve the usual finish, double the amount of starch should be used.

– New dark coloured garments should be washed and dried separately from light coloured garments to avoid the danger of colours running and discolouring other garments or even plastic components in the appliance. Dark coloured fibres can also settle on light coloured garments and vice versa.

Brief instructions

The headings numbered (❶, ❷, ❸ ...) show the operating sequence and can be used as a brief guide to using your dryer.

❶ Sort the laundry

To ensure an even drying result separate the washed laundry and sort it according to:
. . . the drying level required
. . . the type of fibre or weave
. . . size
. . . the moisture content after spinning.

⚠ Make sure that objects e.g. detergent dispensing balls have been removed from the laundry. They could melt, and cause damage to the dryer or the laundry.

– Check seams and stitching to ensure that padding and linings are intact.

– Fasten duvet covers and pillow cases to prevent small items from being trapped inside them.

– Fasten hooks and eyes etc.

– Tie fabric belts and apron strings.

– Sew in or remove underwiring from bras.

❷ Turn on the tumble dryer

■ Switch the dryer on by pressing the I O button.

The tumble dryer may be switched on after loading, saving energy as the lighting will not come on.

❸ Load the tumble dryer

■ Press the *Door* button to open the door.

■ Load the laundry loosely into the drum.

Do not overload the drum. See the "Programme chart" for recommended loads for each programme.
Overloading can cause unnecessary wear and tear to the laundry and give a disappointing drying result.

■ Before closing the door make sure the fluff filter is correctly positioned.



Check the laundry is right inside the drum so that it cannot get trapped or damaged when the door is shut.

■ Shut the door either with a gentle swing, or lean against it and push it shut.

❹ Select a programme



■ Select the programme you want.

The indicator light for the programme selected will light up.
A drying level or additional option(s) indicator light may also light up, or a time may appear in the display (Memory function).

Programmes with drying levels: *Cottons, Minimum iron, Delicates, Automatic, Shirts* and *Denim*



■ Press the Drying level button repeatedly until the indicator light for the drying level you want lights up.

Any of the drying levels can be selected for the *Cottons* programme. A more limited range is available when using other programmes.

Important: Please note that the programme duration shown in the display will vary according to the programme selected (see "Programme duration / Estimated time remaining").

You cannot alter the drying level of the *Woollens handcare* and *Smoothing* programmes.

***Cool air* and *Warm air* programmes**

The indicator light for the *Delay start* button will flash when the *Cool air* or *Warm air* programme is selected.

■ Press the *Delay start* button repeatedly until the required duration shows in the display.

You can select a duration of *15/20* minutes up to *2:00/1:00* hours in 10 minute steps (*Warm/Cool air*).

❺ Select any additional options

■ The *Low temperature, Buzzer, and Delay start* additional options are selected by pressing the appropriate button (see "Additional options" for more details).

N.B.: It is not possible to select Delay start when using the *Warm air* or *Cool air* programme.

❻ Start the programme

The *Start/Stop* button will flash when a programme is being selected. The flashing indicates that a programme can be started.

- Press the *Start/Stop* button.

The *Start/Stop* button will now light up constantly.

Drying will appear in the display and the time remaining will start counting down.

Before the end of a programme

There is a cooling down phase at the end of the drying sequence (*Cooling down* will appear in the display). The programme will not finish until the cooling down phase has been completed.
There is no cooling down phase at the end of the following programmes: *Woollens handcare, Smoothing.*

❼ Remove the laundry when the programme has finished

0 and *Finish* will appear in the display to indicate that the programme has finished. The buzzer (if selected) will sound at intervals.

The drum will continue to rotate at intervals to prevent laundry creasing, if you do not wish to remove it immediately **(anti-crease)**. The anti-crease phase lasts for two hours. There is no anti-crease phase at the end of the *Woollens handcare* programme.

- Press the *Door* button.
- Open the door.
- Remove the laundry.

> Check that all items have been removed from the drum. If items are left in the dryer, they could be damaged by overdrying when the dryer is next used.

If the dryer is switched on at the mains and the door is opened, the drum lighting will come on. It will go out a few minutes later to save energy.

- Switch the dryer off by pressing the I O button.
- After every cycle, remove the fluff from the fluff filter in the door.
- Close the door.

Low temperature

For all delicate or minimum iron fabrics with the ⊡ symbol on the care label (e.g. acrylic garments).

– The programme duration is longer.

– On some programmes *Low temperature* is a standard part of the programme and so cannot be deselected.

Buzzer

A buzzer sounds (at intervals for a maximum of 1 hr) to let you know the programme has finished.

The buzzer will still sound if there is a fault, even if it has been switched off.

Delay start

The start of a programme can be delayed by 30 minutes up to 24 hours to allow you to take advantage of economy electricity at night, for example.

After selecting a programme:

■ Press the *Delay start* button repeatedly until the required delay period shows in the display.

– The *Delay start* indicator light will flash.

– Times of:
up to *10h* are selected in 30 minute steps
more than *10h* in 1 hour steps

– If you keep the *Delay start* button pressed in, the time will continue to increase up to *24h*.

To begin delay start

■ Press the *Start/Stop* button.

– The *Delay start* indicator light will light up constantly.

The delay start time counts down towards the start of the programme as follows:

– more than *10h* by the hour

– less than *10h* in minutes

The drum will turn briefly every hour to help prevent creasing.

While the delay start time is counting down, you can still add laundry to the drum:

■ Switch the dryer off.

■ Open the door and add the laundry.

■ Close the door and switch the dryer back on again.

To cancel/alter delay start

■ Press the *Start/Stop* button.

This cancels delay start.

■ To alter the delay start time, press the *Delay start* button repeatedly until the required delay period shows in the display.

■ Press the *Start/Stop* button.

The altered delay start time will start counting down from the beginning again.

Programme chart

Cottons	**Max. load 6 kg***
Extra dry, Normal**	
Fabric type	Single and multi-layered cotton fabrics such as towelling, jerseywear, T-shirts, underwear.
Notes	– Select *Extra dry* for multi-layered and very thick fabrics. – Do not use *Extra dry* for loopknit fabrics (e.g. T-shirts, underwear), as they have a tendency to shrink.
Low temperature	Select the Low temperature option for delicate fabrics with the ⊡ symbol on the care label.
Hand iron, Machine iron	
Fabric type	Cottons or linen fabrics, e.g.: table linen, bed linen, starched laundry.
Note	– To prevent laundry from drying out it should be rolled up until you are ready for ironing.
Low temperature	Select the Low temperature option for delicate fabrics with the ⊡ symbol on the care label.
Minimum iron	**Max. load 3 kg***
Normal, Hand iron	
Fabric type	Minimum iron items made of cotton, synthetic or blended fabrics, e.g.: shirts, blouses, skirts and table cloths.
Notes	– Select *Hand iron* for delicate fabrics and to reduce creasing even more, reduce the load to 1.5 kg*. – In the Minimum iron programme with the *Hand iron* drying level, items are dried with very little creasing, depending on fabric type and amount of laundry.
Low temperature	Select the Low temperature option for delicate fabrics with the ⊡ symbol on the care label.
Delicates	**Max. load 2 kg***
Normal, Hand iron	
Fabric type	Delicate items made of synthetic fibres, easy care cotton or blended fabrics, e.g. shirts, blouses, lingerie and appliquéd garments.
Low temperature	Low temperature cannot be deselected.

* Weight of dry laundry

** Note for test institutes: Test programme (without selecting Low temperature) in accordance with Regulation 392/2012/EU for energy labelling measured in accordance with EN 61121.

Woollens handcare	**Max. load: 2 kg***
Fabric type	Woollen fabrics
Notes	– This programme only fluffs up woollen garments. They are not dried completely by this programme. – Remove garments as soon as the programme has finished and leave to finish drying at room temperature.
Low temperature	Low temperature cannot be deselected.
Smoothing	**Max. load: 3 kg***
Fabric type	– Cotton and linen fabrics. – Minimum iron items made of mixed fibres, cottons or synthetics, e.g.: trousers, jackets, shirts.
Notes	– Smooths out creasing caused during the spin cycle in the washing machine. – Fabrics are not completely dried in this programme. Remove garments as soon as the programme has finished and leave to finish drying at room temperature.
Low temperature	Low temperature cannot be deselected.
Automatic	**Max. load: 3.5 kg***
Normal, Hand iron	
Fabric type	Mixed loads of garments suitable for the *Cottons* and *Minimum iron* programmes. Sort according to colour.
Shirts	**Max. load: 2 kg***
Normal, Hand iron	
Garments	Shirts and blouses.
Low temperature	Also select the Low temperature option for delicate fabrics with the ⊡ symbol on the care label.
Denim	**Max. load: 3 kg***
Normal, Hand iron	
Fabric type	Denim garments, e.g. jeans, jackets, skirts, shirts.
Low temperature	Also select the Low temperature option for delicate fabrics with the ⊡ symbol on the care label.

* Weight of dry laundry

Programme chart

Cool air	**Max. load: 6 kg***
Fabric type	– Any item which only needs airing.
Warm air	**Max. load: 6 kg***
Fabric type	– Multi-layered fabrics whose layers have different drying characteristics, e.g. jackets, pillows. – For drying individual items, e.g. bath towels, bathing costumes, tea-towels and small loads.
Note	Do not select the longest drying time to start with. Check the items as you are drying them to find the optimum time.
Tip	You can use the *Warm air* programme to help remove odours from cotton clothing which has been worn but it still clean (select a duration of between 1/2 and 1 hour). Items must be suitable for drying in a tumble dryer. Dampen the garments a little beforehand or add a fabric conditioner sheet. The Warm air programme will not be as effective at removing odours from any parts of the garments which are made of synthetic fibres.
Low temperature	Also select the Low temperature option for delicate fabrics with the ⊡ symbol on the care label.

* Weight of dry laundry

Once a programme has started

- changing the programme

You cannot change to another programme once a programme has started (this prevents unintentional alterations).

You will need to cancel the current programme before you can select a new one.

- cancelling the programme and then selecting a different programme

- Press the *Start/Stop* button.

  The items will be cooled down, depending on the temperature reached and how long they have been dried for.

  If you press the *Start/Stop* button again during the cooling down phase, *Finish* will light up in the display.
- Press the *Door* button.
- Close the door.
- Select another programme and start it.

- cancelling the programme and then removing the laundry

- Proceed as described in "Adding or removing laundry after a programme has started" below.
- Switch the dryer off after closing the door.

Altering Delay start

- See "Delay start".

Adding or removing laundry after a programme has started

- Press the *Door* button.
- Open the door.

⚠ Danger of burning:
Do not touch the back of the drum when adding or removing items. The drum and the items can get very hot.

- Add or remove items as required.
- Close the door.
- Press the *Start/Stop* button.

Time remaining

The time left shown in the display may now vary from the actual drying time.

Electronic system lock

The system lock prevents the dryer being used without your knowledge.

It can be activated if wished.

The dryer's electronics are then locked. The dryer can still be switched on but a programme cannot be started.

– If an attempt is made to start a programme, the indicator light for the *Low temperature* button will come on and a key symbol *0-o* will appear in the display.

The door is not locked and can be opened at any time.

To activate the lock

Before you begin, first ensure that:

– The tumble dryer is switched off.

– The door is closed.

❶ Press the *Low temperature* button and keep it pressed in whilst carrying out steps ❷ to ❺.

❷ Press the I o button in.

The *Automatic* indicator light will come on.

❸ Slowly turn the programme selector three positions stage by stage in a clockwise direction.
Each of the three programme indicator lights must come on one after the other.

❹ Now slowly turn the programme selector six positions stage by stage in an anti-clockwise direction.
Each of the six programme indicator lights must come on one after the other.

The indicator light for the *Low temperature* button will flash and a key symbol *0-o* will appear in the display.

❺ Release the *Low temperature* button.

The electronics have now been locked.

■ Switch the dryer off.

To deactivate the lock

Before you begin, first ensure that:

– The tumble dryer is switched off.

– The door is closed.

■ The procedure is the same as for activating the lock. Carry out steps ❶ to ❺ as described previously.

At step ❺ the indicator light for the *Low temperature* button will stop flashing and the key symbol *0-o* will go out.

The electronics are no longer locked.

Cleaning the fluff filter

The fluff which is created by the drying process is collected in the fluff filter in the door. Clean the filter after **each** drying cycle*.

* Always check the fluff filter if the *Clean out airways* indicator light comes on.

Cleaning whilst dry

Tip: You can also use a vacuum cleaner to remove the fluff.



- Open the door and pull the fluff filter (1) out of the door as illustrated.



- Use your fingers to remove the fluff from the surface of the filter.
- Remove any fluff from the hollow part of the door opening. You could also use a cleaning brush which is available as an optional extra from your Miele dealer or the Miele Spare Parts Department, or use a vacuum cleaner.
- Also clean the door seal (2) with a damp cloth.
- Once clean, push the filter back into the door holder until it clicks into position. Ensure it is facing the correct way. Close the door.

Cleaning with water

If there is still a great deal of compacted fluff on the filter after cleaning it as described above, you can clean it with water.

- Rinse the filter under hot, running water.
- Dry the filter carefully and thoroughly.

Cleaning the grilles in the door opening

Clean the grilles in the door opening and also the area underneath them from time to time.



- Turn dial ① on each grille until you hear it click.
- Take hold of the dial, and pull the grille out of the door opening as shown ②. Do the same on the other side.
- Clean the grilles under hot running water, and dry thoroughly.
- Also clean the area underneath them, e.g. with a vacuum cleaner.
- Replace by inserting them at the bottom and pressing them into place at the top.
- Lock both dials (you will hear them click).

Cleaning the tumble dryer

Disconnect the tumble dryer from the mains electricity supply.

Miele branded cleaning and conditioning products are available to order via the internet on www.miele-shop.com.

- Clean the housing, control panel and door seal with a slightly damp cloth and a mild detergent or soapy water.
- The drum and other stainless steel parts can be cleaned with a suitable stainless steel cleaner following the manufacturer's instructions.

Do not use solvents, abrasive cleaners, glass cleaners or all-purpose cleaners. These could damage plastic sufaces and other parts. The tumble dryer must never be hosed down.

- Dry all parts with a soft cloth.

With the help of the following notes minor faults in the performance of the appliance, some of which may result from incorrect operation, can be put right without contacting the Service Department.

⚠ Repair work to electrical appliances should only be carried out by a suitably qualified person in strict accordance with current local and national safety regulations. Repairs and other work by unqualified persons could be dangerous. The manufacturer cannot be held liable for unauthorised work.

Check and fault messages

Problem	Possible cause	Remedy
The programme stops and 0 and *Finish* appear in the display. **The buzzer sounds.**	This is not a fault. The electronic unit has recognised that there is no laundry or insufficient laundry in the drum and cancelled the programme. Drying individual garments or items which are already dry can also cause the programme to be cancelled.	Use the *Warm air* programme for drying individual items. – Open and shut the door.
0-o appears in the display. **The *Low temperature* indicator light is flashing.**	The electronic system lock is activated.	You will need to deactivate the system lock before the dryer can be used (see "Electronic system lock").
The programme stops. **The buzzer sounds.** ***Cooling down* or *Finish* may also flash in the display.**	No obvious cause.	– Switch the dryer off and back on again. – Then start the programme again. If this problem happens again, there is a fault. Contact Miele.
Bars are flashing at the end of the programme:	The programme has finished but the laundry is still being cooled down.	You can either unload the drum and leave the laundry to cool at room temperature or leave it in the dryer to continue cooling.

Problem solving guide

Problem	Possible cause	Remedy
The *Clean out airways* indicator light comes on.	The dryer is not working efficiently or economically. Possible cause: the filter is clogged with fluff or with detergent residues.	– Cleaning the filter is usually all that is required. However, if the *Clean out airways* indicator light does not go out after you have cleaned the filter, then also check all the possible causes described under "The drying process goes on too long or even switches off". **To switch off this reminder:** – Open and shut the door with the dryer switched on.
	The vent ducting may be very long, which does not constitute a fault.	If very long ducting is used, then programme times will be longer and energy consumption higher.
		The *Clean out airways* indicator light can be deactivated (see "Programmable functions").
The programme stops and **the *Clean out airways* indicator light comes on.** **The buzzer sounds.**	See above for possible causes and their remedies.	– Try to resolve the problem by following the instructions given above. – If this problem happens again, contact Miele.

Other problems

Problem	Possible cause	Remedy
The drying process goes on too long or even switches off. **In some circumstances, the *Clean out airways* indicator light still comes on, even though the filter is clean.**	**Please check all the possible causes and switch the dryer off and then back on again.**	
	Ventilation to the dryer is insufficient (e.g. because it is installed in a room which is too small).	Open a door or window while the dryer is in operation for increased air flow.
	The fluff filter is blocked.	Remove any fluff.
	The vent ducting or the ventilation outlet is blocked.	– Check all parts of the vent ducting system on a regular basis (e.g. wall pipe, external grille, bends in the ducting etc.) and make sure they are all free of any hindrance. – Remove any fluff.
	The laundry has not been spun sufficiently.	Make sure that your laundry is thoroughly spun at the appropriate spin speed.
	The tumble dryer has been overloaded.	Do not exceed the maximum load for the programme selected.
	Metallic components, e.g. zips, have prevented the dryer from registering the correct moisture level in the laundry.	– Open zips next time. If the problem occurs again, dry garments with long zips using the Warm air programme (timed drying).
The laundry is not sufficiently dry.	The load consisted of different fabrics.	– Finish drying using the Warm air programme. – Select a different programme next time.

Problem solving guide

Problem	Possible cause	Remedy
Items made of synthetic fibres are charged with static electricity after drying.	Synthetic fibres tend to attract static charge.	Static charge can be reduced by adding a fabric conditioner to the final rinse in the washing programme or a fabric conditioner sheet to the load when drying.
There is a build-up of fluff.	Fluff is principally the result of friction when garments are being worn and washed. Machine drying does not affect the lifetime of fabric.	Fluff is collected by the fluff filter and can be easily removed (see "Cleaning and care").

Problem	Possible cause	Remedy
Sometimes a programme cannot be started and the corresponding programme indicator light does not light up.	No obvious cause.	– Switch the dryer off and back on again. – Select one of the programmes. – If it still will not start, there is a fault. Contact the Miele Service Department.
The *Start/Stop* indicator light is flashing slowly and the display is dark.	The dryer is in Standby mode. This is quite normal and not indicative of any fault.	See "Programmable functions".
The tumble dryer fails to start when switched on.	No obvious cause.	– Is the dryer switched on? – Is the plug correctly inserted into the socket and switched on? – Is the door closed properly? – Has the fuse or circuit breaker tripped?
Power cut.	A programme which was running previously will continue automatically when power is restored to the tumble dryer as long as the Cooling down phase had not been reached.	
The interior drum lighting does not come on.	The lighting switches off automatically (to save energy).	Switch the dryer off and then on again.
	The lamp needs changing.	Change the lamp, as described at the end of this section.

Changing the lamp

Disconnect the tumble dryer from the mains electricity supply.

- Open the door.

You will find the interior light cover at the top of the drum aperture.



- Insert a suitable tool, such as a wide bladed screwdriver, under the side edge of the light cover as illustrated.
- Apply a little pressure and whilst doing so turn your wrist in the direction of the arrow to open the cover.

The cover will open downwards.

The temperature resistant lamp should only be ordered from your Miele Dealer or the Miele Spare Parts Department.

The light specification and maximum wattage is stated on the data plate and on the light cover.

- Turn the light anti-clockwise to remove.
- Replace the lamp.
- To close the cover push it upwards and press it on the left and right until you hear it click into position.

⚠ Ensure that it is fitted into position securely, as any moisture could cause a short circuit.

Repairs

In the event of any faults which you cannot remedy yourself, or if the machine is under guarantee, please contact

– Your Miele dealer, or

– the Miele Service Department (see back cover for contact details).

When contacting the your Dealer or the Service Department, please quote the model and serial number of your machine, both of which are shown on the data plate (visible when the door is opened).



N.B. A call-out charge will be applied for unnecessary service visits where the problem could have been rectified as described in this instruction manual.

Future updates (PC)

The indicator light marked **PC** is the interface used by Miele service technicians during service work for testing purposes and for updating the machine's programme data.

Guarantee

Please see the guarantee card supplied with your machine.

Optional accessories

Optional accessories for this dryer are available from your Miele Dealer, the Miele Spare Parts Department or via the internet at www.miele-shop.com.

Please note that telephone calls may be monitored and recorded for training purposes.

Front view



① Venting connection: rear, right or left
(supplied with the rear socket open)

② Mains connection cable

③ Control panel

④ Door

⑤ Four height adjustable screw feet

Rear view



① Protruding lid for holding when moving the machine (see arrows)

② Mains connection cable

③ Venting connection at the rear

Installation site

⚠ The machine lid must not be removed.

The dryer can be pushed under a worktop with its lid in place, providing the worktop is high enough.

⚠ Make sure the dryer door can be opened without hindrance after installation.

Transporting the machine to its installation site

When moving the machine, you can hold it by the lid where it protrudes to the rear of the dryer. To manoeuvre the dryer out of its packing case to its installation site you will also need to hold it by the front feet.

Washer-dryer stack

The tumble dryer can also be combined with a Miele washing machine in a washer-dryer stack. The appropriate "WTV" stacking kit (available to order) to match your dryer is required.

⚠ Stacking kits must only be installed by a suitably qualified fitter.

Levelling the machine



The machine must be perfectly level to ensure safe and proper operation.



- The screw feet can be adjusted to compensate for any unevenness in the floor.

⚠ The gap between the base of the dryer and the floor must not be blocked by deep pile carpets, plinths, etc as this would prevent a sufficient intake of air.

Room ventilation

The dryer operates by drawing in air from the room in which it is located. It is therefore very important to ensure that there is adequate ventilation in the room, by opening a window, for example.
Otherwise running times and energy consumption could be increased.

Electrical connection U.K.

All electrical work should be carried out by a suitably qualified and competent person, in strict accordance with current national and local safety regulations (BS 7671 in the UK).

Ensure power is not supplied to the appliance until after installation work has been carried out.

The appliance is supplied with a mains cable with moulded plug ready for connection to a 230-240V mains supply. Please ensure the connection data quoted on the data plate match the household mains supply.

Connection should be made via a suitable switched socket which is easily accessible after installation.

For extra safety it is advisable to protect the appliance with a suitable residual current device (RCD). Contact a qualified electrician for advice.

Do not connect via an extension lead. Extension leads do not guarantee the required safety of the appliance (e.g. danger of overheating).

Non-rewireable plugs BS 1363

The fuse cover must be refitted when changing the fuse, and if the fuse cover is lost, the plug must not be used until a suitable replacement is obtained. The colour of the correct replacement cover is that of the coloured insert in the base of the plug, or the colour that is embossed in words on the base of the plug (as applicable to the design of plug fitted).

Replacement fuses should be ASTA approved to BS 1362 and have the correct rating. Replacement fuses and fuse covers may be purchased from your local electrical supplier.

WARNING: THIS APPLIANCE MUST BE EARTHED

General

Important

Before operating the tumble dryer, a suitable ducting system must be installed to carry the moist air from the dryer to the outside. This can be:
. . . flexible ducting hose, or plastic piping connected to the dryer, or
. . . the dryer may be connected directly to the wall vent.

– Before installing the ducting system, ensure that the appliance is not connected to the power supply.

– The ducting outlet (e.g. wall pipe) should be installed in such a way that the moist expelled air . . .
. . . cannot be drawn back into the room in which the dryer is installed;
. . . cannot cause any damage to the building or other nuisance.

– The dryer uses the room air. It is therefore essential to ensure adequate ventilation to avoid the **danger of asphyxia** caused by gases given off by other appliances being drawn back into the room. Insufficient ventilation will also cause drying times to be considerably longer.
Ventilation can be maintained by:
- an open window;
- an air inlet which cannot be blocked in windows, doors and outside wall vents;
- a window switch which prevents the dryer being used when the window is closed.

Avoid:

– very long ducting systems

– too many bends or corners, tight corners

Otherwise the drying result will be less effective and it will take longer and use more energy.

Suitable materials

– for the ventilation ducting:
flexible ducting* or plastic piping with a diameter of at least 100 mm.

– for venting to the outside:
a wall pipe kit* or a window vent kit*.

* Available as an optional accessory from your Miele dealer or the Miele Spare Parts Department.

Procedure

■ First measure the duct length required. Calculate the effective duct length and establish the internal duct diameter required (use the tables on the next page).

■ The longer the ducting, the larger the internal diameter of the ducting required.

■ Then decide which type of ducting you want to use (see "Venting systems" in this section).

Calculating the total duct length :

Friction against the inner walls of the ducting will slow down the expelled air as it passes through. An elbow, bend, non-return flap or wall vent creates more friction than a straight duct. The friction created by each of these is expressed as an **additional duct length factor**. The additional length factors are calculated by comparing the friction created by, for example, an elbow to that created by 1 metre of straight plastic piping (Table I).

The additional duct length factor for each item needs to be added together to ascertain the **total duct length** required.

A larger **internal duct diameter** also helps reduce friction. If the total duct length is **more than 20 m** the duct diameter should be increased (Table II).

1. To calculate the total duct length required:

- First measure the distance which will require straight ducting. Multiply this amount by the corresponding additional duct length factor in **Table I**.
- Establish the number of angles, bends etc. necessary and add their additional duct length factors together with the help of **Table I**.
- Add all the additional duct length factors together to get the total duct length.

2. Internal duct diameter

- Refer to **Table II** for the appropriate duct diameter required.

Table I

	Additional duct length factor
Flexible ducting*	
– 1 m laid straight	1.8 m
– 45° angle (Bend radius = 0.25 m)	1.5 m
– 90° angle (Bend radius = 0.25 m)	2.5 m
Flexible aluminium vent hose* / plastic piping	
– 1 m laid straight / or 1 m straight pipe	1.0 m
– 45° angle / elbow (Bend radius = 0.25 m)	0.6 m
– 90° angle / elbow (Bend radius = 0.25 m)	0.8 m
Wall vent kit* or window vent kit*	
– with louvred grille	3.8 m
– with non-return flap (hinged flap)	1.5 m
Non-return flap* to be integrated into the vent ducting	14.3 m
Flat ducting (for washer dryer stack)*	11.0 m
Venting connection to the left/right	1.0 m
*optional accessory from Miele	

Table II

Maximum total duct length allowable	Internal duct diameter required
20 m	100 mm
40 m	125 mm
100 m	150 mm

Calculation example



A	**Wall pipe, with louvred vent**	
	= 1 x 3.8 m Additional duct length	= 3.8 m
B/D	**2 Elbows, 90°**	
	= 2 x 0.8 m Additional duct length	= 1.6 m
C	**0.5 m plastic piping**	
	= 0.5 x 1 m Additional duct length	= 0.5 m
E	**Side connection, left**	
	= 1 m Additional duct length	= 1.0 m
	Total duct length	= 6.9 m

Result: A duct diameter of 100 mm is adequate as the total duct length is less than the 20 m specified in Table II.

Installation to the rear, left or right side of the appliance

At the rear

The dryer is delivered with this connection open.

- Fit one of the venting systems described on the following pages.

Left or right side of the appliance



- Turn the cover flap anti-clockwise.
- Refit it securely in the rear outlet.
- Fit one of the venting systems described on the following pages.

Venting systems

The various venting systems which are possible are described on the following pages.

Ⓐ Flexible ducting hose

Ⓑ Plastic piping

Ⓒ Connecting directly to a wall vent

Ⓐ Flexible ducting hose

This is a simple, cost effective way of directing the moist air outside. The adapter supplied is fitted into the vent opening on the dryer and the 100 mm ∅ ducting hose is then connected to the adapter.

■ The following items are required: . .
. . . flexible ducting hose
. . . a wall vent kit* or window vent kit*.



* (Miele optional accessory).

❶ Insert adapter (1) into the vent opening on the dryer.

❷ Attach the hose (2).

■ Installation examples are shown on the next page.

Installation - venting

Installation examples

Window vent



1. Window vent kit (fitted in a "plexiglass" pane)
   (separate fitting instructions are supplied with the Miele window vent kit)
2. Adapter for flexible hose

Connection to an exhaust flue



1. Pipe with connection piece
   (= supplied with the Miele wall vent kit)
2. Adapter for flexible hose
3. Exhaust flue insulated against damp

⚠ The ducting must not be vented into a chimney or vent flue which is in use, nor should it be connected to ducting which ventilates rooms with fireplaces.

Ⓑ Plastic piping

Plastic piping is a good option where the vented air has to be ducted for some distance. The smooth walls of the pipe create less friction for the vented air than the walls of a flexible vent hose, for example. Time and energy consumption are better with plastic piping.

The following items are required:

– An adapter* (∅ 100 mm).

– A wall vent kit* or window vent kit*.

– Suitable piping (∅ 100 mm) is available from your dealer or builders merchants. Where the pipe diameter is more than 100 mm, an adapter is necessary (e.g. from ∅ 100 to 125 mm) to connect the pipe to the dryer.

* Available as an optional accessory from your Miele dealer or the Miele Spare Parts Department.



■ The plastic pipe (2) is connected to adapter (1) which is fitted into the vent opening on the dryer.

Example



1. Wall vent kit
   (Separate fitting instructions are supplied with the Miele wall vent kit).
2. Adapter
3. Plastic piping, diameter DN 100

Ⓒ Connect directly to a wall vent

The best method of venting the dryer is to connect it directly to the outside wall of a room. Time and energy consumption are better with plastic piping. This involves boring through an outside wall.

A wall pipe* and a flexible foam gasket* must be used
(* Miele optional accessories).

❶ Before drilling into the wall, . .
. . . please read the installation instructions supplied with the Miele wall vent kit.
. . . and study the following diagrams.

View from above:



1. Wall pipe
2. Flexible foam gasket

Side view:



1. Wall pipe
2. Flexible foam gasket



❷ Fit the foam gasket (2) onto the adapter (1) on the wall pipe.

❸ Push the dryer up against the wall.

Washer-dryer stack



Stacking kit* without pull-out shelf:

A = 94.2 cm

B = 170 cm

Stacking kit* with pull-out shelf:

A = 96 cm

B = 172 cm

* Miele accessory available to order

Consumption data

Programme	Load	Final spin speed in a domestic washing machine	Energy	Duration
	kg*	rpm	kWh	Minutes
Cottons Normal	3.0	1000 (60 % residual moisture)**	2.00	53
	6.0	1000 (60 % residual moisture)**	3.58	89
	6.0	1200 (53 % residual moisture)	3.20	81
	6.0	1400 (50 % residual moisture)	3.05	77
	6.0	1600 (48 % residual moisture)	2.70	69
	6.0	1800 (43 % residual moisture)	2.65	68
Cottons Hand iron	6.0	1000 (60 % residual moisture)	2.45	59
	6.0	1200 (53 % residual moisture)	2.15	52
	6.0	1400 (50 % residual moisture)	2.00	49
	6.0	1600 (48 % residual moisture)	1.70	42
	6.0	1800 (43 % residual moisture)	1.65	41
Minimum iron Normal	3.0	1200 (40 % residual moisture)	1.05	30
Minimum iron Hand iron	3.0	1200 (40 % residual moisture)	0.90	26
Delicates Normal	2.0	800 (50 % residual moisture)	1.05	39
Automatic Normal	3.5	800 (50 % residual moisture)	1.80	52
Shirts Normal	2.0	600 (60 % residual moisture)	1.05	29
Denim Normal	3.0	900 (60 % residual moisture)	1.85	51
Woollens handcare	2.0	1000 (50 % residual moisture)	0.15	4
Smoothing	3.0	1000 (60 % residual moisture)	0.30	8

* Weight of dry laundry

** Test programme in accordance with Regulation 392/2012/EU for energy labelling measured in accordance with EN 61121.

All data without a "star" against it was calculated using EN 61121.

Before testing in accordance with EN 61121, dry a 3 kg load of cotton laundry with 70% residual moisture as per the above standard using the Cottons Normal programme without any additional options.

Consumption data can vary from the nominal values given above depending on the size of the load, types of textiles, residual moisture levels after spinning, fluctuations in the electricity supply and any extra options selected.

Height	850 mm
Width	595 mm
Depth	634 mm
Depth with door open	1074 mm
Suitable for pushing under a worktop	Yes
Suitable for stacking	Yes
Weight	46 kg
Drum volume	111 litres
Maximum capacity	6 kg dry weight
Length of connection cable	2 m
Voltage	see data plate
Connected load	see data plate
Fuse rating	see data plate / plug
Lamp wattage	see data plate
Energy consumption	see "Consumption data"
Test certificates awarded	see data plate

Programmable functions for changing default settings

The programmable functions are used to alter the tumble dryer´s electronics to suit changing requirements.
Programmable functions can be altered at any time.

Altering the residual moisture level in the Cottons programme

The tumble dryer is designed to dry effectively using as little energy as possible.
However, if you require the laundry to be drier or damper, you can reduce or increase the default residual moisture in the Cottons programme.

Follow the steps (❶,❷,❸ ...) to programme and store in memory.

Before you begin, ensure that:

– The tumble dryer is switched off.

– The door is closed.

❶ Press the *Start/Stop* button and keep it pressed in whilst carrying out steps ❷-❸.

❷ Switch the dryer on.

Wait until the *Start/Stop* button lights up constantly . . .

❸ . . . and then release the *Start/Stop* button.

– The *Low temperature* indicator light will flash once briefly.

A **number** to show which option is selected will appear in the display alternating with the letter *P*.

0 **Increased residual moisture. Laundry damper.**

1 **Standard residual moisture (factory default setting).**
(the *Automatic* indicator light will also flash once).

2 **Reduced residual moisture. Laundry drier.**
(the *Automatic* indicator light will also flash twice).

❹ Pressing the *Start/Stop* button switches between the options.

❺ Switch the dryer off.

The setting you have selected is now stored in memory. You can change it again at any time.

To check the setting:

■ Carry out steps ❶ to ❸.

■ Switch the dryer off after step ❸.

Altering the residual moisture level in the Minimum iron programme

The tumble dryer is designed to dry effectively using as little energy as possible.
However, if you require the laundry to be drier or damper, you can reduce or increase the default residual moisture in the Minimum iron programme.

Follow the steps (❶,❷,❸ ...) to programme and store in memory.

Before you begin, ensure that:

– The tumble dryer is switched off.

– The door is closed.

❶ Press the *Start/Stop* button and keep it pressed in whilst carrying out steps ❷-❸.

❷ Switch the dryer on.

Wait until the *Start/Stop* button lights up constantly . . .

❸ . . . and then release the *Start/Stop* button.

❹ Press the *Low temperature* button once.

– The *Low temperature* indicator light will flash twice briefly.

A **number** to show which option is selected will appear in the display alternating with the letter *P*.

0 **Increased residual moisture. Laundry damper.**

1 **Standard residual moisture (factory default setting).**
(the *Automatic* indicator light will also flash once).

2 **Reduced residual moisture. Laundry drier.**
(the *Automatic* indicator light will also flash twice).

❺ Pressing the *Start/Stop* button switches between the options.

❻ Switch the dryer off.

The setting you have selected is now stored in memory. You can change it again at any time.

To check the setting:

■ Carry out steps ❶ to ❹.

■ Switch the dryer off after step ❹.

Anti-crease

Anti-crease helps prevent creasing, if laundry is not normally removed immediately after the end of a programme.

The anti-crease function

– is activated when the tumble dryer is delivered. You can shorten the duration of the anti-crease phase or deactivate it if wished.

– is used in all programmes except *Woollens handcare*.

– should be left activated.

Follow the steps (❶,❷,❸ ...) to programme and store in memory.

Before you begin, ensure that:

– The tumble dryer is switched off.

– The door is closed.

❶ Press the *Start/Stop* button and keep it pressed in whilst carrying out steps ❷-❸.

❷ Switch the dryer on.

Wait until the *Start/Stop* button lights up constantly . . .

❸ . . . and then release the *Start/Stop* button.

❹ Press the *Low temperature* button twice.

– The *Low temperature* indicator light will flash 3 times briefly.

A **number** to show which option is selected will appear in the display alternating with the letter *P*.

0 **Anti-crease off**

1 **1 hour anti-crease**
(the *Automatic* indicator light will also flash once).

2 **2 hours anti-crease**
(factory default setting)
(the *Automatic* indicator light will also flash twice).

❺ Pressing the *Start/Stop* button switches between the options.

❻ Switch the dryer off.

The setting you have selected is now stored in memory. You can change it again at any time.

To check the setting:

■ Carry out steps ❶ to ❹.

■ Switch the dryer off after step ❹.

Altering the volume of the buzzer

The buzzer has two volumes.

Follow the steps (❶,❷,❸ ...) to programme and store in memory.

Before you begin, ensure that:

– The tumble dryer is switched off.

– The door is closed.

❶ Press the *Start/Stop* button and keep it pressed in whilst carrying out steps ❷-❸.

❷ Switch the dryer on.

Wait until the *Start/Stop* button lights up constantly . . .

❸ . . . and then release the *Start/Stop* button.

❹ Press the *Low temperature* button three times.

– The *Low temperature* indicator light will flash four times briefly.

A **number** to show which option is selected will appear in the display alternating with the letter *P*.

0 **Normal buzzer (factory default setting)**

1 **Loud buzzer** (the *Automatic* indicator light will also flash)

❺ Pressing the *Start/Stop* button switches between the options.

❻ Switch the dryer off.

The setting you have selected is now stored in memory. You can change it again at any time.

To check the setting:

- Carry out steps ❶ to ❹.
- Switch the dryer off after step ❹.

Altering the standard drying level in the Automatic programme

The tumble dryer is designed to dry effectively using as little energy as possible.
However, if you require the laundry to be drier or damper, you can reduce or increase the default residual moisture in the Automatic programme.

Follow the steps (❶,❷,❸ ...) to programme and store in memory.

Before you begin, ensure that:

– The tumble dryer is switched off.

– The door is closed.

❶ Press the *Start/Stop* button and keep it pressed in whilst carrying out steps ❷-❸.

❷ Switch the dryer on.

Wait until the *Start/Stop* button lights up constantly . . .

❸ . . . and then release the *Start/Stop* button.

❹ Press the *Low temperature* button four times.

– The *Low temperature* indicator light will flash six times briefly.

A **number** to show which option is selected will appear in the display alternating with the letter *P*.

0 **Increased residual moisture. Laundry damper.**

1 **Standard residual moisture (factory default setting).**
(the *Automatic* indicator light will also flash once).

2 **Reduced residual moisture. Laundry drier.**
(the *Automatic* indicator light will also flash twice).

❺ Pressing the *Start/Stop* button switches between the options.

❻ Switch the dryer off.

The setting you have selected is now stored in memory. You can change it again at any time.

To check the setting:

■ Carry out steps ❶ to ❹.

■ Switch the dryer off after step ❹.

Extending the cooling down time

The cooling down phase which takes place before the end of a programme can be extended by 5 or 10 minutes, if required. This makes the garments easier to handle.

The cooling down time can only be extended for programmes with drying levels.

Follow the steps (❶,❷,❸ ...) to programme and store in memory.

Before you begin, ensure that:

– The tumble dryer is switched off.

– The door is closed.

❶ Press the *Start/Stop* button and keep it pressed in whilst carrying out steps ❷-❸.

❷ Switch the dryer on.

Wait until the *Start/Stop* button lights up constantly . . .

❸ . . . and then release the *Start/Stop* button.

❹ Press the *Low temperature* button five times.

– The *Low temperature* indicator light will flash seven times briefly.

A **number** to show which option is selected will appear in the display alternating with the letter *P*.

0 **Cooling down time not extended (factory default setting)**

1 **Cooling down time extended by five minutes**
(the *Automatic* indicator light will also flash once).

2 **Cooling down time extended by ten minutes**
(the *Automatic* indicator light will also flash twice).

❺ Pressing the *Start/Stop* button switches between the options.

❻ Switch the dryer off.

The setting you have selected is now stored in memory. You can change it again at any time.

To check the setting:

■ Carry out steps ❶ to ❹.

■ Switch the dryer off after step ❹.

Standby

To save energy, the display and the programme sequence/check lights go out after 10 minutes and the *Start/Stop* button starts flashing slowly.

To come out of standby mode

- Turn the programme selector or press a button. Neither will have any effect if a programme is running.

On

The standby function is activated and the display and programme sequence/check lights will go out after 10 minutes:

– if a programme is not selected after the dryer has been switched on.

– after a programme has started.

They will, however, come on for 10 minutes after a delay start time has counted down, at the end of the programme or the end of the anti-crease phase.
The buzzer (if selected) will sound for 10 minutes at the end of the programme.

Factory default. Not in current programme

As described under "On" above. However, the display and programme sequence/check lights will stay on after the programme has started and remain visible during the programme.

Off

The display and programme sequence/check lights will stay on while the dryer is switched on.

Follow the steps (❶,❷,❸ ...) to programme and store in memory.

- See next page.

Before you begin, ensure that:

– The tumble dryer is switched off.

– The door is closed.

❶ Press the *Start/Stop* button and keep it pressed in whilst carrying out steps ❷-❸.

❷ Switch the dryer on.

Wait until the *Start/Stop* button lights up constantly . . .

❸ . . . and then release the *Start/Stop* button.

❹ Press the *Low temperature* button six times.

– The *Low temperature* indicator light will flash 8 times briefly.

A **number** to show which option is selected will appear in the display alternating with the letter *P*.

0 **On**

1 **Factory default setting. Not in current programme**
(the *Automatic* indicator light will also flash once).

2 **Off**
(the *Automatic* indicator light will also flash twice).

❺ Pressing the *Start/Stop* button switches between the options.

❻ Switch the dryer off.

The setting you have selected is now stored in memory. You can change it again at any time.

To check the setting:

■ Carry out steps ❶ to ❹.

■ Switch the dryer off after step ❹.

Memory function

The electronics will memorise any extra options selected for a programme. The duration selected for the Warm air or Cool air timed drying programmes will also be stored in memory.
These settings will be selected automatically the next time the programme is chosen. You can either accept these or change them by pressing the appropriate button.

Follow the steps (❶,❷,❸ ...) to programme and store in memory.

Before you begin, ensure that:

– The tumble dryer is switched off.

– The door is closed.

❶ Press the *Start/Stop* button and keep it pressed in whilst carrying out steps ❷-❸.

❷ Switch the dryer on.

Wait until the *Start/Stop* button lights up constantly . . .

❸ . . . and then release the *Start/Stop* button.

❹ Press the *Low temperature* button seven times.

– The *Low temperature* indicator light will flash 9 times briefly.

A **number** to show which option is selected will appear in the display alternating with the letter *P*.

0 **Memory deactivated (factory default setting)**

1 **Memory activated**
(the *Automatic* indicator light will also flash)

❺ Pressing the *Start/Stop* button switches between the options.

❻ Switch the dryer off.

The setting you have selected is now stored in memory. You can change it again at any time.

To check the setting:

■ Carry out steps ❶ to ❹.

■ Switch the dryer off after step ❹.

Clean out airways indicator

Fluff should be removed after drying. The *Clean out airways* indicator will remind you to clean the filters when a certain amount of fluff has collected in the filters. You can decide at what level of fluff this reminder should be given.

You will have an idea of how often this should be done after a few drying programmes.

Follow the steps (❶,❷,❸ ...) to programme and store in memory.

Before you begin, ensure that:

– The tumble dryer is switched off.

– The door is closed.

❶ Press the *Start/Stop* button and keep it pressed in whilst carrying out steps ❷-❸.

❷ Switch the dryer on.

Wait until the *Start/Stop* button lights up constantly . . .

❸ . . . and then release the *Start/Stop* button.

❹ Press the *Low temperature* button eight times.

– The *Low temperature* indicator light will flash on and off slowly once.

A **number** to show which option is selected will appear in the display alternating with the letter *P*.

0 ***Clean out airways*** **indicator light is deactivated**

1 ***Clean out airways*** **indicator light comes on when there is a heavy build-up of fluff**
(the *Automatic* indicator light will also flash once).

2 **Factory default setting**
(the *Automatic* indicator light will also flash twice).

3 ***Clean out airways*** **indicator light comes on when there is only a light build-up of fluff**
(the *Automatic* indicator light will also flash three times).

❺ Pressing the *Start/Stop* button switches between the options.

❻ Switch the dryer off.

The setting you have selected is now stored in memory. You can change it again at any time.

To check the setting:

■ Carry out steps ❶ to ❹.

■ Switch the dryer off after step ❹.

Keypad tone

An audible tone sounds each time a button is pressed.

Follow the steps (❶,❷,❸ ...) to programme and store in memory.

Before you begin, ensure that:

– The tumble dryer is switched off.

– The door is closed.

❶ Press the *Start/Stop* button and keep it pressed in whilst carrying out steps ❷-❸.

❷ Switch the dryer on.

Wait until the *Start/Stop* button lights up constantly . . .

❸ . . . and then release the *Start/Stop* button.

❹ Press the *Low temperature* button nine times.

– The *Low temperature* indicator light will flash on and off slowly once and then on and off quickly once.

A **number** to show which option is selected will appear in the display alternating with the letter *P*.

0 **Keypad tone deactivated (factory default setting)**

1 **Keypad tone activated** (the *Automatic* indicator light will also flash)

❺ Pressing the *Start/Stop* button switches between the options.

❻ Switch the dryer off.

The setting you have selected is now stored in memory. You can change it again at any time.

To check the setting:

■ Carry out steps ❶ to ❹.

■ Switch the dryer off after step ❹.

Adjusting the dryer's electronics for very soft water

⚠ In some areas of the UK, water is extremely soft which can affect the sensitivity of the control electronics. If the dryer is installed in an area of very soft water, you should contact your local water supplier for information and advice regarding water hardness and water conductivity. If the water conductivity is less than 150 µS, the following programmable function will need to be activated.

Important. This programmable function should not be activated if, despite the water being extremely soft (as would be the case if a water softener were used), its conductivity is greater than 150 µS.

Follow the steps (❶,❷,❸ ...) to programme and store in memory.

Before you begin, ensure that:

– The tumble dryer is switched off.
– The door is closed.

❶ Press the *Start/Stop* button and keep it pressed in whilst carrying out steps ❷-❸.

❷ Switch the dryer on.

Wait until the *Start/Stop* button lights up constantly . . .

❸ . . . and then release the *Start/Stop* button.

❹ Press the *Low temperature* button ten times.

– The *Low temperature* indicator light will flash on and off slowly once and then on and off quickly twice.

A **number** to show which option is selected will appear in the display alternating with the letter *P*.

0 **Factory default setting**

1 **Adjusted for very soft water** (the *Automatic* indicator light will also flash)

❺ Pressing the *Start/Stop* button switches between the options.

❻ Switch the dryer off.

The setting you have selected is now stored in memory. You can change it again at any time.

To check the setting:

- Carry out steps ❶ to ❹.
- Switch the dryer off after step ❹.

Extending the range of the drying levels

You can extend the range of the drying levels for many of the programmes:
Machine iron+
(drier than Machine iron).
Slightly dry
(drier than Hand iron).
Normal+
(drier than Normal).

This programmable function is only available for programmes with drying levels.

Follow the steps (❶,❷,❸ ...) to programme and store in memory.

Before you begin, ensure that:

– The tumble dryer is switched off.

– The door is closed.

❶ Press the *Start/Stop* button and keep it pressed in whilst carrying out steps ❷-❸.

❷ Switch the dryer on.

Wait until the *Start/Stop* button lights up constantly . . .

❸ . . . and then release the *Start/Stop* button.

❹ Press the *Low temperature* button eleven times.

– The *Low temperature* indicator light will flash on and off slowly once and then on and off quickly three times.

A **number** to show which option is selected will appear in the display alternating with the letter *P*.

0 **Default setting**

1 **Drying level range extended**
(the *Automatic* indicator light will also flash).

❺ Pressing the *Start/Stop* button switches between the options.

❻ Switch the dryer off.

The setting you have selected is now stored in memory. You can change it again at any time.

To check the setting:

■ Carry out steps ❶ to ❹.

■ Switch the dryer off after step ❹.

To select the extended drying level

■ Select a programme.

■ Press the drying level button repeatedly until the following indicator lights come on.

– Indicator lights *Extra dry* and *Normal* = Normal+

– Indicator lights *Normal* and *Hand iron* = Slightly dry

– Indicator lights *Hand iron* and *Machine iron* = Machine iron+

United Kingdom
Miele Co. Ltd.
Fairacres, Marcham Road
Abingdon, Oxon, OX14 1TW
Tel: 0845 365 0555, Fax: 0845 365 0777
Customer Contact Centre Tel: 0845 365 6600
E-mail: info@miele.co.uk
Internet: www.miele.co.uk

Australia
Miele Australia Pty. Ltd.
ABN 96 005 635 398
1 Gilbert Park Drive, Knoxfield, VIC 3180
Tel: 1300 464 353, Fax: (03) 9764 7149
Internet: www.miele.com.au

China
Miele (Shanghai) Trading Ltd.
1-3 Floor, No. 82 Shi Men Yi Road
Jing' an District
200040 Shanghai, PRC
Tel: +86 21 6157 3500, Fax: +86 21 6157 3511
E-mail: mieleshanghai@cn.miele.com
Internet: www.miele.cn

Miele (Hong Kong) Limited
41/F - 4101, Manhattan Place
23 Wang Tai Road
Kowloon Bay
Hong Kong
Tel: (852) 2610 1331, Fax: (852) 2610 1013
Email: mielehk@miele.com.hk

India
Miele India Pvt. Ltd.
Ground Floor, Copia Corporate Suites
Plot No. 9, Jasola
New Delhi – 110025
Tel: 011-46 900 000, Fax: 011-46 900 001
E-mail: customercare@miele.in, Internet: www.miele.in

Ireland
Miele Ireland Ltd.
2024 Bianconi Avenue
Citywest Business Campus, Dublin 24
Tel: (01) 461 07 10, Fax: (01) 461 07 97
E-Mail: info@miele.ie, Internet: www.miele.ie

Manufacturer: Miele & Cie. KG
Carl-Miele-Straße 29, 33332 Gütersloh, Germany

Malaysia
Miele Sdn Bhd
Suite 12-2, Level 12
Menara SapuraKencana Petroleum
Solaris Dutamas No. 1, Jalan Dutamas 1
50480 kuala Lumpur, Malaysia
Phone: +603-6209-0288
Fax: +603-6205-3768

New Zealand
Miele New Zealand Limited
Unit L, 10-20 Sylvia Park Road
Mt. Wellington, 1060, Auckland, NZ
Tel: 0800 264 353, Fax: 0800 463 453
Internet: www.miele.co.nz

Singapore
Miele Southeast Asia
Miele Pte. Ltd.
163 Penang Road
04 - 02/03 Winsland House II
Singapore 238463
Tel: +65 6735 1191, Fax: +65 6735 1161
E-Mail: infosea@miele.com.sg
Internet: www.miele.sg

South Africa
Miele (Pty) Ltd
63 Peter Place, Bryanston 2194
P.O. Box 69434, Bryanston 2021
Tel: (011) 875 9000, Fax: (011) 875 9035
E-mail: info@miele.co.za
Internet: www.miele.co.za

United Arab Emirates
Miele Appliances Ltd.
P.O. Box 11 47 82
Gold & Diamond Park
Sheikh Zayed Road
Building 6 / Offices Nos. 6-214 to 6-220
Dubai
Tel: +971-4-341 84 44
Fax: +971-4-341 88 52
E-Mail: info@miele.ae, Internet: www.miele.ae

Alteration rights reserved/0113

M.-Nr. 07 856 790 / 04

CE